











How much container can be loaded into a container?

Loading pallets into a container is a task that requires careful consideration of various factors such as the size of the pallets, the dimensions of the container, weight restrictions, and any specific regulations or guidelines. The number of pallets that can be loaded into a container can vary depending on these factors.

Generally, standard shipping containers come in several sizes, with the most common being 20-foot and 40-foot containers. The number of pallets that can fit into a container depends on the size of the pallets and how they are arranged.

Below we made an overview with the most used containers sizes and the pallets that can be loaded.

Pallet Type	20 ft Container	40 ft Container
Standard, North American 48" x 40" inch 122 x 102 cm	 10 pallets	 20 pallets
Standard, North American 42" x 42" inch 107 x 107 cm	 10 pallets	 22 pallets
Standard, North American 48" x 48" inch 1212 x 122 cm	 5 pallets	 10 pallets
Standard EUR2, European 47,24" x 39,37" inch 120 x 100 cm	 10 or 11 pallets	 20 or 21 pallets
Standard EUR1, European 31,50" x 47,24" inch 80 x 120 cm	 11 pallets	 23 or 24 pallets

Please note! Dimensions are a guideline only.

For more help and support, please contact DB Logistics.